

INSTALLATION DETAILS

Amber 3238

(45 gal. Capacity)

NO FLANGE
2 SIDE PANELS

NO EXTENSION PANEL NEEDED

★ **Use Aftermarket Tile Flange if required by local code.**

IMPORTANT:
Pre drill 2 screw holes in the tub tile flange on the back of the tub only. Use these two holes to screw the tub to studs. Do not over tighten screws. **Do not force tub flange to studs, this can cause the tub door to not seal properly and could possibly cause a door leak.**



NO FLANGE ON 3 SIDES DETAIL A

